

ARDUINO NANO 33 BLE WITH HEADERS

Code: ABX00034

This board is based on the [nRF 52840](#) microcontroller.

Clock 64MHz

Flash 1MB

RAM 256KB

Please note: Arduino Nano 33 BLE only supports 3.3V I/Os and is **NOT** 5V tolerant so please make sure you are not directly connecting 5V signals to this board or it will be damaged. Also, as opposed to Arduino Nano boards that support 5V operation, the 5V pin does NOT supply voltage but is rather connected, through a jumper, to the USB power input.

The Bluetooth is managed by a [NINA B306](#) module.

The IMU is a [LSM9DS1](#) and it is managed through I2C.

The board has a two 15 pins connectors - one on each side -, pin to pin compatible with the original Arduino Nano.

Pin	Funcion	Type	Description
1	D13/SCK	Digital	SPI SCK; GPIO
2	+3V3	Power Out	Internally generated power output to external devices
3	AREF	Analog	Analog Reference; can be used as GPIO
4	A0/DAC0	Analog	ADC in/DAC out; can be used as GPIO
5	A1	Analog	ADC in; can be used as GPIO
6	A2	Analog	ADC in; can be used as GPIO
7	A3	Analog	ADC in; can be used as GPIO
8	A4/SDA	Analog	ADC in; I2C SDA; Can be used as GPIO (*)
9	A5/SCL	Analog	ADC in; I2C SCL; Can be used as GPIO(*)
10	A6	Analog	ADC in; can be used as GPIO
11	A7	Analog	ADC in; can be used as GPIO
12	V _{USB}	Power In/Out	Normally NC; can be connected to V _{USB} pin of the USB connector by shorting a jumper
13	RST	Digital In	Active low reset input (duplicate of pin 18)
14	GND	Power	Power Ground
15	VIN	Power In	Vin Power input

16 TX	Digital	USART TX; can be used as GPIO
17 RX	Digital	USART RX; can be used as GPIO
18 RST	Digital	Active low reset input (duplicate of pin 13)
19 GND	Power	Power Ground
20 D2	Digital	GPIO
21 D3/PWM	Digital	GPIO; can be used as PWM
22 D4	Digital	GPIO
23 D5/PWM	Digital	GPIO; can be used as PWM
24 D6/PWM	Digital	GPIO; can be used as PWM
25 D7	Digital	GPIO
26 D8	Digital	GPIO
27 D9/PWM	Digital	GPIO; can be used as PWM
28 D10/PWM	Digital	GPIO; can be used as PWM
29 D11/MOSI	Digital	SPI MOSI; can be used as GPIO
30 D12/MISO	Digital	SPI MISO; can be used as GPIO

(*) As opposed to other Arduino Nano boards, pins A4 and A5 have an internal pull up and default to be used as an I²C Bus so usage as analog inputs is not recommended. Opposed to Arduino Nano boards that support 5V operation, the 5V pin does NOT supply voltage but is rather connected, through a jumper, to the USB power input.

On the bottom side of the board, under the communication module, **debug signals** are arranged as 3x2 test pads with 100 mil pitch. Pin 1 is the bottom left one with the USB connector on the left and the test pads on the right.

Pin	Function	Type	Description
1	+3V3	Power Out	Internally generated power output to be used as voltage reference
2	SWD	Digital	nRF52480 Single Wire Debug Data
3	SWCLK	Digital In	nRF52480 Single Wire Debug Clock
5	GND	Power	Power Ground
6	RST	Digital In	Active low reset input