


USB: USER USB: POWER + DEBUG

	5V	1
PIO0_16	ADC0_n	2
PIO0_23	ADC0_p	3
PIO0_15	GPIO	4
PIO1_5	GPIO	5
PIO1_8	GPIO	6
PIO1_9	GPIO	7
PIO1_10	GPIO	8
PIO0_14	FC1_SCL	9
PIO0_13	FC1_SDA	10
PIO0_27	FC2_TXD	11
PIO1_24	FC2_RXD	12
PIO1_31	PLU_INO	13
PIO0_0	COMP	14
	RESET ULP	15
	GND	16



1	VDD	
2	LED R	PIO1_4
3	LED G	PIO1_7
4	LED B	PIO1_6
5	FC4_SCL	PIO1_20
6	FC4_SDA	PIO1_21
7	GPIO	PIO0_7
8	GPIO	PIO1_0
9	GPIO	PIO0_31
10	SSEL1	PIO1_1
11	SCK	PIO1_2
12	MISO	PIO1_3
13	MOSI	PIO0_26
14	GPIO	PIO1_27
15	GPIO	PIO1_26
16	WAKE / GPIO	

SW203	SW202	SW201	SW200
PIO0_5	PIO1_9	WAKEUP	RESET